


BP555 Electronic Gummed Paper Tape Dispenser Guide

Water bath with brush

On/off switch (rear) Cover with safety cut off Control panel with set lengths Water Tank Heater/weight plate Heater setting



Automatic Mode kit

Automatic mode means that when a piece of tape is removed form the dispenser, another piece will be dispensed straight away. This can be used with up to 3 different tape lengths, dispensing in order.

• To activate automatic mode, ensure any dispensed tape has been removed, then press "A"

To Repeat one tape length

- Press the button of the desired length and remove the tape
- Press "Repeat 2/Enter"
- Press "Repeat/Start"

To Repeat two tape lengths

- Press the button of the desired length and remove the tape
- Press "Repeat 2/Enter"
- Press the button of the second desired length and remove the tape
- Press "Repeat 2/Enter"
- Press "Repeat/Start"

To repeat three tape lengths

- Press the button of the desired length and remove the tape
- Press "Repeat 2/Enter"
- Press the button of the second desired length and remove the tape
- Press "Repeat 2/Enter"
- Press the button of the third desired length and remove the tape
- Press "Repeat 2/Enter"
- Press "Repeat/Start"

kite

Loading Tape



- Open the cover (the power will automatically shut off)
- Place the tape between the guide plates



- Pass the tape over the bar at the back.
- Feed the tape to the wheel and roll it through.



- Close the cover.
- Press the feed button on the control panel.

Maintenance



Weekly

- Remove the water tank and lift brush out the water bath.
- Rinse/soak the brush with warm soapy water.



Monthly

- Open cover
- Pull manual blade release.
- 2 drops of oil on blade